

Specific vehicle alarm fitting instructions

Brand: **VW**

Model: **TOUAREG**

Year: **2007** →



26 Pin Connector

Function

Pin Number	Wire Colour	Function
16	Violet	LBO
1	Orange-green	Can H
2	Orange-brown	Can L

6 Pin Connector

Function

Pin Number	Wire Colour	Function
6	Black-green	LBC

Specific vehicle alarm fitting instructions

Brand: **VW**Model: **TOUAREG**Year: **2007** →**Relays 433****Pin
Number****Wire
Colour**

85

Brown-
violet

Block